







## **OPERATING MODE:**

- Lower the sliding lever and secure the latch to use the top of the blade as a cutter.
- Raise the sliding lever to use as utility scissors / pincers
- Your SUPER-CUT has a **LOCKING LATCH** to keep the blade in the closed position. You can store it safely

## **INSTRUCTIONS FOR CHANGING BLADES:**

- Be careful; always wear protective gloves to change the blade.
- Unscrew the 2 screws holding the blade.
- Carefully remove the blade and replace it with a new one (replacement blades are located at the bottom of the SUPER-CUT handle).
- Fix the screws.

## **MAINTENANCE INSTRUCTIONS:**

- Store in a place protected from moisture
- Caution, always wear protective gloves to clean the SUPER-CUT and the blade.

## WARNING:

CUT.

Avoid contact with the blades. Wear safety gloves. Read all of these instructions carefully and keep them for future reference. This product is not a toy. Keep out of reach of children. Be careful, the blades are extremely sharp. For your safety, handle your SUPER-CUT with the utmost care. Avoid contact with the blades. Always wear protective gloves. . Do not put your fingers under the blade. Do not hold the blade by your fingers, but use the handles to operate your SUPER-

